



## **Included Hardware:**

1 pcRVSCRB1/4-20 x 1.25 SHCS Clamping Rod Bolt1 pcRVSBB1/2-13 x 1 SHCS Mounting Bracket Bolt1 pcRVSPAB1/4-20 x 1.75 SHCS Pivot Arm Bolt1 pcRVSPCW1/4" Washer for Pivot Clamp

## **To Order Entire Kits:**

**RVSKL100** - Vise Stop Kit - **LEFT HAND MOUNT** for standard 6" vise, includes all items above except RVSRB, which can be ordered separately

**RVSKR100** - Vise Stop Kit - **RIGHT HAND MOUNT** for Standard 6" vise includes all items above except RVSLB, which can be ordered separately

## **VersaStop - Set up and Use:**

Your RedLine Tools VersaStop is shipped ready to attach to your vise.

For correct installation, rest the mounting bracket square on vise ways and fasten it with the supplied 1/2-13 socket head cap screw. Insert the desired stop rod into the stop rod clamp, position to desired length and tighten the clamp to 30 in/lbs. Warning never tighten over 40 in/lbs.

Position the stop by loosening the pivot clamp screw. Once in position, tighten pivot clamp screw. Do not exceed 100 in/lbs.

Your VersaStop is supplied with 1/4" diameter stop rods. Your VersaStop will accept stop rods from 1/16" to 3/8" in diameter. Clearance issues may arise when using stop rods smaller than 1/4" diameter. A shorter or longer bolt may need to be used when using other stop rods.

Any questions please contact us at:

